

## **DFENGXING**

Joyear

B11

DIAS immobiliser(4G93)

ECU identification

Fault codes

Erase DTC

Live data

Program function

Add a key

Erase keys

Program new system

Replace engine ECU

Check key

Check engine ECU

Actuation test

LED status

DIAS immobiliser(1.8T K4)

ECU identification

Fault codes

Erase DTC

Live data

Program function

Add a key

Erase keys

Program new system

Replace engine ECU

Check key

Check engine ECU

Actuation test

LED status

B12

DIAS Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program function

Add a key

Erase keys

Program new system

Replace engine ECU

Check key

Check engine ECU

Actuation test

LED status

BH5 Series(BH5/BH5 LV/BH5A)

Immobiliser

UAES K line immobiliser

UAES CAN line immobiliser

BX5 Series(BX5/BX5A)

Immobiliser

UAES K line immobiliser

UAES CAN line immobiliser

BCM Immobiliser

Program new system

Change BCM

Replace engine ECU

Add a key

Erase keys

Immobilizer Program information read

The number of read transponder key

(PEPS) Immobiliser

Program BS3,1.8T other old models

Program new system

Replace immobiliser ECU

Replace engine ECU

Add a key

Erase keys

Check key

Program ESCL

EMS reset

PEPS(IMMO) Program information

reading

Matching new models

Program new system

Replace immobiliser ECU

Replace engine ECU

Add a key

Erase keys

Check key

Program ESCL

EMS Reset

PEPS(IMMO) Program information

reading

BCM

UAES BCM

Aftermarket program

Program RKE key

Delete RKE key

PEPS

(BX5A/BS3/CM7) PEPS

Program BS3,1.8T other old models

Program new system

Replace immobiliser ECU

Replace engine ECU

Add a key

Erase keys

Check key

Program ESCL

EMS reset

PEPS(IMMO) Program information

reading

Matching new models

Program new system

Replace immobiliser ECU

Replace engine ECU

Add a key

Erase keys

Check key

Program ESCL

EMS Reset

PEPS(IMMO) Program information

reading

BX3 Series

Immobiliser

UAES K line immobiliser

UAES CAN line immobiliser

VX

DIAS immobiliser

BCM Immobiliser

UAES BCM

(PEPS) Immobiliser

S50 Series(BS3)

Immobiliser

UAES K line immobiliser

UAES CAN line immobiliser

BCM Immobiliser

Program new system

Change BCM

Replace engine ECU

Add a key

Erase keys

Immobilizer Program information read

The number of read transponder key

(PEPS) Immobiliser

Program BS3,1.8T other old models

Program new system

Replace immobiliser ECU

Replace engine ECU

Add a key

Erase keys

Check key

Program ESCL

EMS reset

PEPS(IMMO) Program information

reading

Matching new models

Program new system

Replace immobiliser ECU

Replace engine ECU

Add a key

Erase keys

Check key

	Program ESCL
	EMS Reset
	PEPS(IMMO) Program information
reading	
	PEPS
	PEPS(X5/S50/CM7)
	Program BS3,1.8T other old models
	Program new system
	Replace immobiliser ECU
	Replace engine ECU
	Add a key
	Erase keys
	Check key
	Program ESCL
	EMS reset
	PEPS(IMMO) Program information
reading	
	Matching new models
	Program new system
	Replace immobiliser ECU
	Replace engine ECU
	Add a key



Erase keys

Check key

Program ESCL

EMS Reset

PEPS(IMMO) Program information

reading

BCM

UAES BCM

Aftermarket program

Program RKE key

Delete RKE key

SX5

DIAS immobiliser

BCM Immobiliser

UAES BCM

(PEPS) Immobiliser

SX6

DIAS immobiliser

BCM Immobiliser

UAES BCM

(PEPS) Immobiliser

XV Series

BCM

UAES BCM

Immobiliser

UAES K line immobiliser

UAES CAN line immobiliser

BCM Immobiliser

(PEPS) Immobiliser

Others

Immobiliser

UAES K line immobiliser (4G93)

UAES CAN line immobiliser (With 2010 and earlier

1.8T models)

CM7

Immobiliser

UAES K line immobiliser

UAES CAN line immobiliser

BCM Immobiliser

(PEPS) Immobiliser

BCM

UAES BCM

PEPS

PEPS(X5/S50/CM7)

S500

Immobiliser

UAES K line immobiliser

UAES CAN line immobiliser

BCM Immobiliser

(PEPS) Immobiliser

PEPS

PEPS(X5/S50/CM7)

BCM

UAES BCM

F600/L

DIAS immobiliser

BCM Immobiliser

UAES BCM

(PEPS) Immobiliser