

## **BMW**

Disable and Enable keys

CAS3(CAN)

Enable keys

Disable keys

CAS4(CAN)

Read keys information

Keys ID

Keys status

Current ignition key NO.

Enable keys

Disable keys

K Line

Read version information

Read keys information

Keys ID

Keys status

Remote battery status

Current ignition key NO.

Enable keys

Disable keys