

CHANGAN

Benben

Benben mini

Remote system

Remote number

Remote program

New Benben

Remote system

Remote number

Remote program

Benben 2013

Integrated BCM(B501)

Add remote

Erase remote

Live data

Benben(Old)

Chongqing integrated Immobiliser

Basic function

Identification data

Fault codes

Erase DTC

System state

Program function

Set security code

Program date

Program VIN

Erase keys

Program keys

Reset immobiliser

Reset engine ECU

Replace engine ECU

Replace immobiliser ECU

CM8

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Jiexun

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Leimeng

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Yuexiang

V3/V5

Integrated BCM(B501)

Type 1

Add remote

Erase remote

Live data

Type 2

Remote number

Remote program

Atech BCM

Add remote

Erase remote

Live data

V7

Integrated BCM(C201)

Add remote

Erase remote

Live data

Read password

Remote system(Smart key)

Erase DTC

Program remotes

Key number

Smart key system

Erase DTC

Program smart keys

Key number

Zhixiang

Atech BCM

Add remote

Erase remote

Live data

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Auchan

Smart key system

Erase DTC

Program smart keys

Key number

Ruipin

Integrated BCM(C201)

Add remote

Erase remote

Live data

Read password

Remote system

Erase DTC

Program remotes

Read key number

Smart key system

Erase DTC

Program smart keys

Read key number

B301

Atech BCM

Add remote

Erase remote

Live data

CX20

Atech BCM

Add remote

Erase remote

Live data

Integrated BCM(B501)

Add remote

Erase remote

Live data

CX30

Atech BCM

Add remote

Erase remote

Live data

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Integrated BCM(B501)

Add remote

Erase remote

Live data

CX70

Atech BCM

Key number

Add remote

Smart key system

Erase DTC

Program smart keys

Key number

CS15

Remote system

Add remote

Erase remote

Live data

Read password

Smart key system

Erase DTC

Program smart keys

Read key number

CS35

-2015

Delphi BCM

Program keys

Erase keys

Add remote

Erase remote

Enter sleep mode

Data configuration

VIN modify

PIN modify

K Line immobiliser enable

enable

disable

With the speed of automatic locking function

On

Off

2016

Remote system

Type 1

Add remote

Erase remote

Live data

Read password

Type 2

Erase DTC

Program remotes

Key number

Smart key system

Erase DTC

Program smart keys

Read key number

CS75

Integrated BCM(C201)

Add remote

Erase remote

Live data

Read password

Remote system

Erase DTC

Program remotes

Read key number

Smart key system

Erase DTC

Program smart keys

Read key number

CV7

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

CV9

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

EADO

Integrated BCM(C201)

Add remote

Erase remote

Live data

Read password

EADO Hybrid

Integrated BCM(C201)

Add remote

Erase remote

Live data

Read password

EADO Pure electric

Integrated BCM(C201)

Add remote

Erase remote

Live data

Read password

EADO XT

Integrated BCM(C201)

Add remote

Erase remote

Live data

Read password

Honor

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Atech BCM

Add remote

Erase remote

Live data

ZunXing

DIAS Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program Function

Program keys

Erease keys

Program new system

Program Immo ECU

Program ECM ECU

Reset Immo ECU

Reset ECM ECU

Read VIN

Key Check

Ecm Ecu Check

Program ECM VIN

Program IMMO VIN

Lock IMMO

Active Test

LED Light Status