
BEATURN(EPB)

X80

Skip the installation location

Under control

End control

Stop Control

Braking command

Under control

End control

Stop Control

Release command

Under control

End control

Stop Control

B90

Skip the installation location

Under control

End control

Stop Control

Braking command

Under control

End control

Stop Control

Release command

Under control

End control

Stop Control