

ROOT

ROEWE

Immobiliser

350

-2012

Add a key

Erase keys

2013-

Add a key

Erase keys

360

Add a key

Erase keys

550

-2012

Add a key

Erase keys

Remaining unlock time

2013-

Add a key

Erase keys

Remaining unlock time

950

With smart

All smart keys lost

Add a smart key

Erase DTC

Live data

Without smart

All keys lost

Erase DTC

Live data

W5

Type 1

Add a key

Erase keys

Type 2

Add a key

Erase keys

RX5

With smart

Program smart key

Erase smart key

Without smart

Add a key

Erase keys

Remote

750

Program remote

Position 1

Position 2

Position 3

Position 4

Position 5

Read remote ID

Position 1

Position 2

Position 3

Position 4

Position 5

Disable remote

Position 1

Position 2

Position 3

Position 4

Position 5

Enable remote

Position 1

Position 2

Position 3

Position 4

Position 5

Erase DTC

360

MG

Immobiliser

GS

With smart

Program smart key

Erase smart key

Without smart

Add a key

Erase keys

GT

Add a key

Erase keys

Remaining unlock time

MG3

Add a key

Erase keys

Remaining unlock time

MG5

Add a key

Erase keys

Remaining unlock time

MG6

-2012

Add a key

Erase keys

Remaining unlock time

2013-

Add a key

Erase keys

Remaining unlock time

MG7

2013-

Add a key

Erase keys

Remaining unlock time

Remote

MG3(Old model)

Program remote

Erase remotes

Read emergency password

Read VIN

MG7

Program remote

Position 1

Position 2

Position 3

Position 4

Position 5

Read remote ID

Position 1

Position 2

Position 3

Position 4

Position 5

Disable remote

Position 1

Position 2

Position 3

Position 4

Position 5

Enable remote

Position 1

Position 2

Position 3

Position 4

Position 5

Erase DTC