

YOUNG LOTUS

Select from type

Siemens Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Original Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Program function

Program keys

Erase keys

UAES immobiliser

Select from vehicle

L3

L5