

**DFPV**

S30/H30/H30 CROSS

S30/H30 CROSS(TU5JP4-ME7.4.4)

Immobiliser

Program keys

Program decoder

Replace engine ECU

Program keys and engine ECU

Configuration

S30/H30 CROSS(TU5JP4-ME7.8.8)

Immobiliser

S30/H30 CROSS(DFM A15-MT22.1)

Immobiliser

Program remote

A60

A60-HR16,MR20

BCM

BCM1

Read BCM code

Release steering lock

BCM2

Read BCM code

Release steering lock

Immobiliser

Immobiliser1

Program keys

Immobiliser2

Erase DTC

Program keys

Immobiliser3

Match the intelligent key directly

Immobiliser4

Match the intelligent key directly

A60-A16

BCM

Program keys

PEPS

Program keys

A60-A14T

BCM

Program keys

A30

BCM

Offline program remote key

Aftermarket program remote key

Immobiliser

Program remote

AX3

AX3(DFM A15 MT22.1)(Key start)

BCM

Program remote key

Immobiliser

Program remote

AX3(DFM A14T MT62.1)(Key start)

BCM

Program remote key

Immobiliser

Program remote

AX3(DFM A14T MT62.1)(Button start)

PEPS

Program keys

AX7

PEPS

Program keys

BCM

Program keys

Electric cars

A60EV

BCM

Program keys

L60

Immobiliser

Add Key